




Top Mount

 WTB3100AK/WK
 WTB3400AK/WK



Minimum Recommended Airspaces



If you have a cupboard above the refrigerator with a rear gap of less than 100mm (Y), recommended minimum clearance at the top of the refrigerator increases from 50mm to 100mm (X).



Please note: Doors are designed to sit proud of cabinetry (not flush).



When positioned in a corner area, spacing of at least 400mm on the hinge side will allow the doors to open enough to enable the removal of bins and shelves.

Dimensions	Product Height (H)	Product Width (W)	Product Depth (D)	Product Depth (D2) (Door Open)
WTB3100AK	1646	598	650	1199
WTB3100WK	1646	598	650	1199
WTB3400AK	1756	598	650	1199
WTB3400WK	1756	598	650	1199

Airspace	Side - both	Top	Behind
WTB3100AK	30	90	50
WTB3100WK	30	90	50
WTB3400AK	30	90	50
WTB3400WK	30	90	50

IMPORTANT

These dimensions are a guide only. All measurements are in millimetres (mm). For complete installation instructions, refer to the manual provided with product.
 © 2021 Electrolux Home Products Pty Ltd. ABN 51 004 762 341. W_DIM_TM_WTB3100-400_Oct21